


DESB (TRUCK SCALE ASSEMBLY)



Dimension

DESB (TRUCK SCALE ASSEMBLY)



Cap. tf	A	A'	B	B'	C	C'	D	E	F	G	H	I	J
22.5 - 34	180	450	190	320	20	25	285	M16x2.0	132	400	M20x2.5	90	90

All dimensions are in mm.

NOTE: For (45 - 100) tf capacities contact Sensotech

SENSOTECH

2/675." THE PALMS", 1st cross Street, Ranga Reddy Gardern, Neelankarai, Chennai-600041

Tel: +19- 44943305 /9176370667/7305716667

Email : sales@sensotechindia.com /sensotechindia@gmail.com

Website: www.sensomaticloadcell.com / sensomaticloadcell.net